




**System Configuration with the 500kV Super-Circuits Unbundled**  
With one of the 500kV Claireville-to-Cherrywood circuits out-of-service



**System Configuration with the 500kV Super-Circuits Unbundled**  
 With one of the 500kV Claireville-to-Cherrywood circuits out-of-service, and following a double-circuit contingency involving the companion line



*System Configuration with the 500kV Super-Circuits Unbundled  
 With one of the 500kV Cherrywood-to-Bowmanville circuits out-of-service*



**System Configuration with the 500kV Super-Circuits Unbundled**  
 With one of the 500kV Cherrywood-to-Bowmanville circuits out-of-service,  
 and following a double-circuit contingency involving the companion line

